

## Preparation

Connect the receiver to a computer via the **U485** USB converter as described in the receiver's user manual. If open, close the **RWW** (Relacart Wireless Workbench) control software. Open the utility program to change the password.

## Changing the password



- 1 Enter there receiver's identification number.
- 2 Select the port used at the USB converter.
- 3 Click on **Connect** to establish the data link to the receiver.
- 4 The current password is indicated.
- 5 Enter the new password and confirm with **OK**. A dialog will inform you about the successful password change. You can disconnect the receiver from the computer now.